


Button Fix Type 1

Nylon PA6

Connects parallel panels where the emphasis is on strength. Highly versatile, it can be surface-mounted or semi-rebated into the panel, orientated for vertical or sideways assembly.

Part Number	Description
04-171001-1	Type 1 Fix
04-171001-11	Type 1 Fix + button fix for CSK wood screw

For easy screw positioning use the Red "Marker Tool"
Part number 04-171005-1.




Button Fix Type 1 Flush

Nylon PA6

For applications where panel-to-panel contact is required. It fits a simple oval rebate and can be rebated into the edge of a panel of at least 28mm thick or the face of a panel of at least 18mm thick.

Part Number	Description
04-171018-1	Type 1 Flush Fix
04-171018-11	Type 1 Flush Fix + button fix for CSK wood screw

For easy screw positioning use the Red "Marker Tool"
Part number 04-171005-1.



Button Fix Type 1 Bonded

ABS

For use where screw-fixing to the panel is not possible and bonding is the preferred option. It can be either surface-mounted or semi-rebated and works with a broad range of materials.

Part Number	Description
04-171017-1	Type 1 Bonded Fix
04-171017-11	Type 1 Bonded Fix + button fix for CSK wood screw

For easy screw positioning use the Red "Marker Tool"
Part number 04-171005-1.

